



FLOWIN® Sport

Important Care Instructions

- 1) DO NOT STORE THE FLOWIN® SPORT IN DIRECT SUNLIGHT (SUCH AS OUTSIDE OR NEAR WINDOWS) OR NEAR HEAT SOURCES. Direct sunlight or excessive heat (like the high temperatures that can occur in the trunk of a car) can cause the board to deform. Though the product can continue to be used, deformation may cause the original friction and functionality to change.
- 2) Do Not store your FLOWIN® Sport in a hot vehicle.
- 3) Avoid contacting the FLOWIN® Sport gliding surfaces with sharp or abrasive objects (such as sand). Sharp or abrasive objects may cause structural changes to the surface of the board. Always use the FLOWIN® Sport in a clean environment and with clean shoes.
- 4) If necessary clean the surface of the board with denatured alcohol.
- 5) When stored rolled up for a long time the board might curl when put on the floor. Then roll it up reversed and leave it for a day or two.
- 6) Refer to the Manual for further safety instructions.